


Elastomeric Formliners - Handling & Storage Recommendations

HANDLING

- To avoid damages resulting from mishandling, caution should be used in unloading and moving formliners with a forklift or other equipment.
- Upon delivery, formliner should be unrolled to a flat surface.
- Use only Architectural Polymers approved release agents. Contact a representative for product recommendations including form oil, release agents and mold dressings.
- Concrete abrasives from continuous casting and removing of the formliner will result in normal wear of a pattern. Replacement or repair is pro rate from number of casts.


STORAGE

- Avoid direct sunlight. Exposure to UV rays cause material distortions and damage.
- Store formliner in a dry location; texture side down. Water causes swelling of rubber in the formliner.
- Do not store heavy objects on top of formliners.
- Store formliner on a flat surface, indoors at room temperature. The amount of expansion and shrinkage is calculated by temperature difference per degree of Fahrenheit. A 30° temperature difference can result in a maximum chage up to 1 ½ inches.



Result of overexposure to sunlight

Formliner Length (inches) x (25 x 10⁻⁵) per degree Fahrenheit = Max Shrinkage



Correct Storage



Do not store formliners rolled.

© 2019 Architectural Polymers, Inc.

1220 Little Gap Road | Palmerton, PA 18071 | 610-824-3322 | www.apformliner.com

The information contained herein is considered accurate; however Architectural Polymers, Inc. makes no warranty regarding the accuracy of the information. The user must determine the suitability of the product for the intended use and accepts all risks and liability associated with that use.